



NOTES:

1. APPLY CCW-550 PRIMER OR CCW-CONTACT ADHESIVE TO ENTIRE SURFACE AREA.
2. APPLY CCW-500R HOT APPLIED WATERPROOFING SYSTEM TO ENTIRE SURFACE AREA.
3. INSTALL CCW PROTECTION BOARD.
4. INSTALL CCW MIRADRAIN DRAINAGE COMPOSITE.

DETAIL IS INTENDED TO BE A GUIDE FOR
WATERPROOFING INSTALLATION ONLY.

500-10A

INSULATED PLAZA DECK

CARLISLE
COATINGS & WATERPROOFING

© 2012 CARLISLE CORPORATION